



BIOGRÜNDL, S.L.
POLÍGONO LES FALLULLES, NAVE 34 -SECTOR 2-
08620 SANT VICENÇ DELS HORTS, BARCELONA (SPAIN)
PHONE: +34 93 660 55 12 / FAX: +34 93 660 55 13
www.biogrundl.es
info@biogrundl.es

CAPTURE-ANTIOX SERUM

1. Aqua	c.s.p. 100
Carbomer	0,650
Potassium sorbate	0,600
2. Glycerin	5,000
3. Caprylic/capric glycerides	5,000
CAPTURE-ANTIOX COMPLEX	0,050
4. ANTIAGE HIALURON HYDRANT	10,000
5. Triethanolamine	0,600
Aqua	0,500
6. Parfum	c.s.p. 100

PROCEDURE

Heat the water and 3. components at 75-80°C.

Add carbomer on water incorporating it well with turbine agitation. Next, add 2.

Emulsify pouring out 3. components on 1.+2. components with turbine agitation.

Continue stirring to complete the said emulsion (10-15 minutes).

Allow to cool with slow stirring (paddle), at about 50°C added 4. components, with turbine agitation.

Add 5. Mixture components with slow stirring (paddle). Continue stirring until complete incorporation. Finally, between 35 and 40°C, perfume with slow stirring.

Note: pH should be between 6.0 and 6.5. If necessary, adjusted with triethanolamine.

Products supplied by BIOGRÜNDL S.L.